






Remove spool cover




Remove spool



Using pliers, gently pull out the orange feed lever straight out (avoid prying which may break lever)



Snap in the black feed lever
*note orientation of lever before inserting



Replace the spool and spool cover

If you have difficulty please CALL 1-800-544-6986
1-800-54HOW-TO